



FIG. 2

FIG. 3



§ →

FIG. 4



SET BASS

APPLICATION

502

MANUAL INPUT EVENT MESSAGE 1) INCREMENT SLIDER VALUE

SLIDER ROUTINE

506

2) PAINT THE SCREEN WITH

NEW SLIDER VALUE

3) CHECK IF SLIDER VALUE IS

MAXIMUM OR MINIMUM, IF MAXIMUM OR MINIMUM DO

NOT UPDATE DISPLAY

FIG. 5A

FIG. 5B